











INSTALLATION INSTRUCTIONS

SIDEMOUNT PULLOUT 300 MM

TOOLS REQUIRED:
















30 MIN

CARE AND MAINTENANCE:


- Clean with a damp cloth and wipe parts dry
- Lubricate pivot points as needed







i ai ta Liat		
No.	Description	Qty
Α	Slide	1 Set
В	Frame	1
С	Baskets	2
D	Door Mounting Bracket	1 Set
Е	Slide Cover	1
F	M5 x 6 mm Pan Head Screws	2
G	4G x 18 mm Pan Head Screws	8
Н	4G x 18 mm Flat Head Screws	8
- 1	M4 x 25 mm Pan Head Screws	2
.J	M4 x 4 5 mm Pan Head Screws	2

Parts List



















CHOOSING THE DESIRED BOTTOM SHELF

The shelf on the basket is reversable. You can have a white or gray bottom. To change the color remove the (4) M4 x 4.5mm pan head screws from the bottom of the shelf. Choose the desired color by flipping the shelf. Install the bottom shelf back by screwing the (4) M4 x 4.5mm pan head screws back into the unit. (See Figure A).



STEP 1

Attach the slides to the frame with the (2) M4 x 25 mm pan head screws. Once secure, engage the slides by placing the back of the frame on the back of the slides and press the slides down until you hear a click (See Figure B).





STEP 2


Attach the cover to the top slide by using (2) of the M5 \times 6 mm pan head screws (See Figure C).



FIGURE A







STEP 3

Using the measurements in **Figure D**, attach the frame assembly to the cabinet with (6) 4G x 18 mm pan head screws.







STEP 4

Using the measurements in Figure E, attach the (2) door mounting brackets to the cabinet door using (8) of the 4G x 18 mm flat head screws (See Figure E).








STEP 5

Take the long middle screw out of the bracket. Slide them onto the slides, line the holes up, and screw the long screw back into its middle slot (See Figure F).








STEP 6

Attach the baskets to the slides. Pay close attention to the hook placement when placing the basket into the unit. (See Figure G).



DOOR ADJUSTMENT

If the cabinet door is not lining up correctly, use the images in **Figures H-1 and H-2** to loosen and tighten the door mounting screws to properly adjust the cabinet door.



