









INSTALLATION INSTRUCTIONS

GLIDING DRAWER SYSTEM

TOOLS REQUIRED:
















30 MIN


CARE AND MAINTENANCE:

- Clean with a damp cloth and wipe parts dry
- Lubricate pivot points as needed






A.



Parts List		
No.	Description	Qty
Α	Shelves	1
В	Slide Set	1 Set
С	Logo Caps	2
D	4G x 18 mm Pan Head Wood Screws	16
Е	Small Bin	1
F	M4 x 4.5 mm Pan Head Screws	2
G	Mounting Bracket	1 Set
Н	Door Mounting Bracket	1 Set
Ī	M4 x 6 mm Machine Screws	4
J	Double Sided Tape	2














CHOOSING THE DESIRED BOTTOM FOR THE UNIT

Unscrew the M4 \times 4.5 mm Pan Head Screws from the bottom of the shelf, choose the desired color by flipping the shelf and reinstall the bottom shelf. (See Figure A)



STEP 1

Using measurements from Figure B predrill hole locations and install the slides using (6) 4G x 18 mm Pan Head Screws.











STEP 2

Place the back of the shelves on the back of the slides. This engages the hook mechanism, then press the slides down. You will hear a click, and the slides are engaged. (See Figure C)

FIGURE A






FIGURE B





STEP 3

Use the images in **Figure D** to adjust the slides based on the cabinet thickness of 16 mm, 18 mm, or 20 mm.



STEP 4

Remove the logo caps from the unit, by popping them off. Once the caps are removed, secure the mounting brackets to the unit with (4) M4 x 6 mm machine screws. (See Figure E)

Reattach the logo caps



FIGURE D





FIGURE E



STEP 5

Using measurements from Figure F predrill hole locations, be careful not to drill through door. Attach the door mounting brackets to the cabinet door with (8) 4G x 18 mm Pan Head Screws.





Loosen the bracket screws on the mounting bracket engage the hook of the door mounting bracket onto the mounting bracket, and tighten the screw to secure the door to the unit. (See Figure G)



DOOR ADJUSTMENT

If the cabinet door is not lining up correctly, use the images in Figure H to loosen and tighten the door mounting screws to properly align the cabinet door.



